AGIS NOVA PRO CONTROLLER - connection diagram