AGIS DIESEL D12 - connection diagram